





















Originale	Sostituto
 Power	 Power
 Preset Up	 Ch +
 Preset Down	 Ch -
 AUX	 Smart
 Tuner/Band	 Media
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Sleep	 Sleep
 Program	 Shift + Sleep
 D.Skip	 3D
 Play/Pause	 Pause
 Stop	 Stop
 >>/>>	 >>
 <</<<	 <<
 Repeat	 Text
 Play Tape	 Play

Originale	Sostituto
 << Tape	 <<
 >> Tape	 >>
 Tape 2	 Green
 Tape 1	 Red
 Rec/Pause Tape	 Rec
 Stop Tape	 Shift + Stop
 EQ PATT.	 Dual
 XDSS	 Subt
 Surr.	 AV
 MP3 Info	 Info
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7



