



























































| Originale | Sostituto |
|---|---|
|  Power |  Power |
|  TV |  Shift + 1 |
|  Caption |  Subtitle / EQ |
|  AV Mode |  Eject / Surround |
|  []/Ratio |  TV/Radio / |
|  Input |  AV / Input / RDS |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  List |  Smart / List |
|  0 |  0 |

| Originale | Sostituto |
|--|---|
|  Flashbk |  Text / Goto |
|  Vol+ |  Vol+ |
|  FAV |  Fav / Marker / PC |
|  CH/Page- |  CH- / Page- |
|  CH/Page+ |  CH+ / Page+ |
|  Vol- |  Vol- |
|  Audio |  Audio / Lang I/II |
|  Mute |  Mute / Dimmer |
|  Picture |  Picture / Format |
|  Info |  Info / Angle |
|  Sound |  Sound / Title |
|  Settings |  Setup / OPT / |
|  Up |  Up |
|  Q.Menu |  D.Menu / Top |
|  Left |  Left |
|  OK |  OK |
|  Right |  Right |





| Originale | Sostituto | Originale | Sostituto |
|-----------|-----------|-----------|-----------------------------|
| | Back | | Back / Return |
| | Down | | Down |
| | Exit | | Exit / Cancel / Clear |
| | Simplink | | Display / Media |
| | Sleep | | Sleep / Timer |
| | Stop | | Stop / Hold |
| | << | | << / Tune- |
| | Play | | Play / Slow |
| | Pause | | Pause / Step / Freeze |
| | >> | | >> / Tune+ |
| | Red | | Red / Netflix / Search |
| | Green | | Green / APP / Repeat |
| | Yellow | | Yellow / YouTube / Repeat |
| | Blue | | Blue / Prime Video / Random |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

