

































































Originale	Sostituto
 Power	 Power
 Open/Close	 Eject / Surround
 Power Tv	 Shift + Power
 DVD	 Shift + 2
 HDD	 Shift + 7
 AV	 AV / Input / RDS
 AV Tv	 Smart / List
 1	 1
 2	 2
 3	 3
 PR+ Tv	 Shift + CH+ /
 4	 4
 5	 5
 6	 6
 PR- Tv	 Shift + CH- /
 7	 7
 8	 8

Originale	Sostituto
 9	 9
 Vol+ Tv	 Vol+
 Tv/DVD	 TV/Radio /
 0	 0
 Mute Tv	 Mute / Dimmer
 Vol- Tv	 Vol-
 Display	 Display / Media
 Text	 Text / Goto
 Tv/Radio	 Shift + TV/Radio / Program
 Rec	 Rec / Rec Mode
 Zoom	 Zoom / Size
 Repeat	 Shift + Green / APP /
 << / Tune-	 << / Tune-
 >> / Tune+	 >> / Tune+
 I<< / Preset-	 I<< / Preset-
 >>I / Preset+	 >>I / Preset+
 Pause	 Pause / Step / Freeze





Originale		Sostituto		Originale		Sostituto	
	Play		Play / Slow		Marker		Fav / Marker / PC
	Stop		Stop / Hold		Search		Shift + Red / Netflix /
	Home		Shift + Menu /		Dubbing		D.Menu / Top
	Up		Up		Clear		Exit / Cancel / Clear
	PR+		CH+ / Page+		Tilte		Setup / OPT /
	Menu/List		Menu / Home		Thumbnail		Sound / Title
	Left		Left		Random		Shift + Blue / Prime
	Enter		OK		CHP.ADD		Picture / Format
	Right		Right		PIP		Audio / Lang I/II
	Guide		Guide / EPG / -/--		Showview		Subtitle / EQ
	PR-		CH- / Page-				
	Down		Down				
	Return		Back / Return				
	Red/FAV		Red / Netflix / Search				
	Green/Audio		Green / APP / Repeat				
	Yellow/Subtitle		Yellow / YouTube / Repeat				
	Blue/Timeshift		Blue / Prime Video / Random				

