



Originale	Sostituto
1	TV 1
2	DVD 2
3	CD - STB 3
4	VIDEO 4
5	TAPE 5
6	TUNER 6
7	AUX - HDD 7
8	USB 8
9	BLUETOOTH 9
0	HDMI - SAT 0
MUTE	DIMMER MUTE Mute / Dimmer
Vol-	VOL - Vol-
Vol+	VOL + Vol+
MONO	LANG I/II AUDIO Audio / Lang I/II
Bal L	Left
Bal R	Right
RECORD	REC MODE Rec / Rec Mode

Originale	Sostituto
LISTEN	TITLE SOUND Sound / Title
AUX	SHIFT + 7 Shift + 7
TP 1	SHIFT + 4 Shift + 4
TP 2	SHIFT + 5 Shift + 5
TUN	SHIFT + 6 Shift + 6
PH 1	SHIFT + TV 1 Shift + 1
PH/AUX 2	SHIFT + DVD 2 Shift + 2
CD	SHIFT + CD - STB 3 Shift + 3























































Originale	Sostituto
	<< / Tune-
	Left
	<< / Preset-
	>> / Tune+
	Right
	>>  / Preset+
	Green / APP / Repeat
	Blue / Prime Video / Random
	Yellow / YouTube / Repeat
	Red / Netflix / Search
	Setup / OPT /
	D.Menu / Top
	Audio / Lang I/II
	1
	2
	3
	4

Originale	Sostituto
	5
	6
	7
	8
	9
	0
	Mute / Dimmer
	Vol+
	Vol-





	Originale	Sostituto	Originale	Sostituto
	I<< Skip	 I<< / Preset-		 6
	Skip >>I	 >>I / Preset+		 7
	Open	 Eject / Surround		 8
	<< Search	 << / Tune-		 9
	Search >>	 >> / Tune+		 0
	Play	 Play / Slow		 Mute / Dimmer
	< Index	 Left		 Vol-
	Index >	 Right		 Vol+
	Display	 Display / Media		
	Pause	 Pause / Step / Freeze		
	Repeat	 Green / APP / Repeat		
	Stop	 Stop / Hold		
	1	 1		
	2	 2		
	3	 3		
	4	 4		
	5	 5		

