



Originale	Sostituto
 Power	 Power
 Mute	 Mute
 P.Mode	 Shift + Format
 S.Mode	 Shift + Dual
 Nicam / A2	 Dual
 Sleep	 Sleep
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/--	 Guide

Originale	Sostituto
 Recall	 Pre Ch
 FAV	 Shift + Pre Ch
 Fav +	 Shift + Up
 Fav -	 Shift + Down
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Source	 AV
 Info	 Info
 Up	 Up
 Right	 Right
 Down	 Down
 Left	 Left
 OK	 Ok
 Menu	 Menu
 Exit	 Exit





Originale	Sostituto
Vol +	Vol +
Vol -	Vol -
Media	Media
TV / Radio	TV/R
CH +	Ch +
CH -	Ch -
Play/Pause / Text	Play
Play/Pause / Text	Pause
Play/Pause / Text	Text
<< / Size	<<
<< / Size	3D
>> / Reveal	>>
Stop / Hold	Stop
I<< / Index	I<<
>>I / Subpage	>>I
Cancel	Shift + Exit
Subtitle	Subt

Originale	Sostituto
Rec	Shift + Text
Timeshift	Smart
A-B	Back
EPG	Format

