




















Originale		Sostituto		Originale		Sostituto	
	Power		Power		Exit		Exit
	Mute		Mute		Up		Up
	1		1		Left		Left
	2		2		OK		Ok
	3		3		Right		Right
	4		4		Down		Down
	5		5		FAV / SAT		Pre Ch
	6		6		Sleep		Sleep
	7		7		Vol -		Vol -
	8		8		Vol +		Vol +
	9		9		IPTV		Smart
	0		0		A/V+		AV
	Info		Info		Option		Options
	Recall		Back		Red		Red
	Menu		Menu		Green		Green
	TV/Rad		TV/R		Yellow		Yellow
	EPG		Guide		Blue		Blue





Originale	Sostituto
PVR List	List
SubT / TXT	Subt
SubT / TXT	Text
PVR Info	+  Shift + Info
Func	Format
T.Shift	Ch +
Jump	Ch -
Rec	Rec
Play / Pause	Play
Play / Pause	Pause
Mark	+  Shift + Pre Ch
<<	<<
Stop	Stop
>>	>>

Originale	Sostituto

