



Originale	Sostituto	Originale	Sostituto
Power	Power	FAV-	Shift + CH- /
Mute	Mute / Dimmer	CH+	CH+ / Page+
1	1	P.Mode	Picture / Format
2	2	Vol+	Vol+
3	3	CH-	CH- / Page-
4	4	S.Mode	Sound / Title
5	5	Vol-	Vol-
6	6	Source	AV / Input / RDS
7	7	Sleep	Sleep / Timer
8	8	Aspect	Shift + Picture / Format
9	9	Info	Info / Angle
-/--	Shift + Guide / EPG / -/--	Up	Up
0	0	Left	Left
Recall	Back / Return	OK	OK
Audio	Audio / Lang I/II	Right	Right
FAV+	Shift + CH+ /	Menu	Menu / Home
FAV	Fav / Marker / PC	Down	Down

Originale	Sostituto	Originale	Sostituto
Power	Power	FAV-	Shift + CH- /
Mute	Mute / Dimmer	CH+	CH+ / Page+
1	1	P.Mode	Picture / Format
2	2	Vol+	Vol+
3	3	CH-	CH- / Page-
4	4	S.Mode	Sound / Title
5	5	Vol-	Vol-
6	6	Source	AV / Input / RDS
7	7	Sleep	Sleep / Timer
8	8	Aspect	Shift + Picture / Format
9	9	Info	Info / Angle
-/--	Shift + Guide / EPG / -/--	Up	Up
0	0	Left	Left
Recall	Back / Return	OK	OK
Audio	Audio / Lang I/II	Right	Right
FAV+	Shift + CH+ /	Menu	Menu / Home
FAV	Fav / Marker / PC	Down	Down





Originale	Sostituto
Exit	Exit / Cancel / Clear
Text	Text / Goto
Index	Display / Media
Play/Mix	Play / Slow
Pause	Pause / Step / Freeze
Stop/Reveal	Stop / Hold
<</Hold	<< / Tune-
<</Hold	Shift + Stop /
>>/Subpage	>> / Tune+
Size	Zoom / Size
I<<	I<< / Preset-
>>I/Cancel	>>I / Preset+
T-Shift	Smart / List
Tv/Radio	TV/Radio /
Rec	Rec / Rec Mode
EPG	Guide / EPG / -/--
Red	Red / Netflix / Search

Originale	Sostituto
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random

