







































































| Originale | Sostituto |
|--|---|
|  Power |  Power |
|  [i]/Info |  Info |
|  Mute |  Mute |
|  I-II |  Dual |
|  OK/Select |  Ok |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  -/--/+10 |  Shift + Guide |
|  Exit |  Exit |

| Originale | Sostituto |
|--|---|
|  Menu |  Menu |
|  Red/1/Return |  Red |
|  Green/↓/Subtitle |  Green |
|  Yellow/Audio |  Yellow |
|  Blue/Angle |  Blue |
|  Up |  Up |
|  Down |  Down |
|  Right |  Right |
|  Left |  Left |
|  P+ |  Ch + |
|  P- |  Ch - |
|  Vol+ |  Vol + |
|  Vol- |  Vol - |
|  Play |  Play |
|  Pause |  Pause |
|  Stop |  Stop |
|  << |  << |





| Originale | Sostituto |
|---|---|
|  >> |  >> |
|  [TV] |  TV/R |
|  D-Menu |  Smart |
|  TV |  Media |
|  AV |  AV |
|  P<P |  Pre Ch |
|  PP |  D. Menu |
|  [≡] |  Text |
|  [≡o] |  Subt |
|  [≡+] |  Format |
|  [≡x] |  3D |
|  [≡◆]/Wide |  SHIFT +  PICTURE FORMAT Shift + Format |
|  [≡?] |  Options |
|  [≡i]/Guide |  Guide |
|  [::]/Subtitle |  Back |

| Originale | Sostituto |
|-----------|-----------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |





| Originale | Sostituto |
|--|--|
|  Power |  Power |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  -/--/+10 |  Guide |
|  Exit |  Exit |
|  Red/↑/Return |  Red |
|  Green/↓/Subtitle |  Green |
|  Yellow/Audio |  Shift + Yellow |
|  Blue/Angle |  Blue |

| Originale | Sostituto |
|---|--|
|  Stop |  Stop |
|  Play |  Play |
|  Pause |  Pause |
|  D-Menu |  Smart |
|  << |  << |
|  >> |  >> |
|  << |  << |
|  >> |  >> |
|  Time |  Shift + AV |
|  Zoom |  Shift + Eject |
|  Program |  Sleep |
|  Search Mode |  AV |
|  Repeat |  Text |
|  A-B |  Shift + Play |
|  C |  Yellow |
|  Title |  Info |
|  Display |  Shift + Info |





| Originale | Sostituto | Originale | Sostituto |
|------------|-----------|-----------|-----------|
| Open/Close | Eject | | |
| Menu | Menu | | |
| Select | Ok | | |
| Up | Up | | |
| Down | Down | | |
| Left | Left | | |
| Right | Right | | |
| Vol+ | Vol + | | |
| Vol- | Vol - | | |
| Mute | Mute | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

