







































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		FAV		Pre Ch
	Tv/VCR		Smart		OPT		Options
	Mute		Mute		←		Back
	Info		Info		1		1
	Pause		Pause		2		2
	Menu		Menu		3		3
	EPG		Guide		4		4
	Exit		Exit		5		5
	Up		Up		6		6
	Down		Down		7		7
	Right		Right		8		8
	Left		Left		9		9
	OK		Ok		0		0
	CH+		Ch +		Tv/Rad		TV/R
	CH-		Ch -		Lang		Dual
	Vol+		Vol +		S-T		Subt
	Vol-		Vol -		TXT		Text



