



| Originale | | Sostituto | | Originale | | Sostituto | |
|-----------|-------|-----------|----------------------------|-----------|--------------|-----------|-----------------------------|
| | Info | | Info / Angle | | 0 | | 0 |
| | Power | | Power | | Blue/Video | | Shift + 4 |
| | TV | | TV/Radio / | | Blue/Video | | Blue / Prime Video / Random |
| | AV | | AV / Input / RDS | | Yellow/Sound | | Sound / Title |
| | R | | Shift + TV/Radio / Program | | Yellow/Sound | | Yellow / YouTube / Repeat |
| | F1 | | Shift + 1 | | PR+ | | CH+ / Page+ |
| | F2 | | Shift + 2 | | Up | | Up |
| | F3 | | Shift + 3 | | White | | Fav / Marker / PC |
| | 1 | | 1 | | Left | | Left |
| | 2 | | 2 | | OK | | OK |
| | 3 | | 3 | | Right | | Right |
| | 4 | | 4 | | Green/Timer | | Sleep / Timer |
| | 5 | | 5 | | Green/Timer | | Green / APP / Repeat |
| | 6 | | 6 | | PR- | | CH- / Page- |
| | 7 | | 7 | | Down | | Down |
| | 8 | | 8 | | Red/Recall | | Back / Return |
| | 9 | | 9 | | Red/Recall | | Red / Netflix / Search |



