





Originale	Sostituto
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 SUBTL	 Subt
 TV / Sat	 AV
 16:9	 Format
 Sleep	 Sleep
 Up / CH+	 Up

Originale	Sostituto
 Up / CH+	 Ch +
 Down / CH-	 Down
 Down / CH-	 Ch -
 Right / Vol+	 Right
 Right / Vol+	 Vol +
 Left / Vol-	 Left
 Left / Vol-	 Vol -
 OK	 Ok
 Menu	 Menu
 Exit	 Exit
 TXT	 Text
 EPG	 Guide
 Info	 Info
 Audio	 Dual
 M-P	 Smart
 Page+	 >>I
 Page-	 I<<





Originale	Sostituto
Red / SAT	Red
Green / Zoom	Green
Green / Zoom	Eject
Yellow / Pause	Yellow
Yellow / Pause	Pause
Blue / TV/Radio	Blue
Blue / TV/Radio	TV/R
FAV	Pre Ch
Recall	Back

Originale	Sostituto

