





































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 5	 5
 Red/Sound ↑	 Red	 6	 6
 Green/Picture/↓	 Green	 7	 7
 Yellow/Feature	 Yellow	 8	 8
 Blue/Install	 Blue	 9	 9
 [≡]	 Text	 0	 0
 [≡0]	 Options	 P<P	 Pre Ch
 [≡+]	 Subt	 -/--	 Shift + Guide
 [≡x]/[· ·]	 Format	 Vol+	 Vol +
 [/≡]/[*]	 Back	 Vol-	 Vol -
 [+]/[≡♦]/Wide	 3D	 Mute	 Mute
 [≡?]/PC	 Smart	 P+	 Ch +
 [≡i]/Guide	 Guide	 P-	 Ch -
 1	 1	 I-II	 Dual
 2	 2	 [i]/Info	 Info
 3	 3	 TV/DTV	 TV/R
 4	 4	 AV	 AV



