































































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 CH+	 Ch +
 ShowView	 3D	 CH-	 Ch -
 AV	 AV	 Vol+	 Vol +
 Direct Tv Rec	 TV/R	 Vol-	 Vol -
 Rec	 Rec	 HDD	 Media
 1	 1	 DVD	 Smart
 2	 2	 << Slow/Search	 <<
 3	 3	 Slow/Search >>	 >>
 4	 4	 Stop	 Stop
 5	 5	 Pause	 Pause
 6	 6	 Play	 Play
 7	 7	 Top Menu / Direct Navigator	 D. Menu
 8	 8	 Menu / Play List	 Menu
 9	 9	 Up	 Up
 0	 0	 Left	 Left
 -/--	 Guide	 Enter	 Ok
 Cancel	 Exit	 Right	 Right







	Originale	Sostituto		Sostituto
	Power		Power	
	CH+		Ch +	
	CH-		Ch -	
	1		1	
	2		2	
	3		3	
	4		4	
	5		5	
	6		6	
	7		7	
	8		8	
	9		9	
	0		0	
	-/--		Guide	
	A		Red	
	B		Green	
	C		Yellow	

	Originale	Sostituto		Sostituto
	D		Blue	

