












































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Title	 Smart
 Open / Close	 Eject	 [-]	 Media
 Mute	 Mute	 Exit	 Exit
 1	 1	 Up / >>>	 >>>
 2	 2	 Up / >>>	 Up
 3	 3	 Left	 Left
 4	 4	 OK / Play	 Ok
 5	 5	 OK / Play	 Play
 6	 6	 Right	 Right
 7	 7	 Down / <<<	 <<<
 8	 8	 Down / <<<	 Down
 9	 9	 ▲ / >>>	 >>>
 0	 0	 ▲ / >>>	 Ch +
 Audio	 Dual	 ▼ / <<<	 <<<
 Subtitle	 Subt	 ▼ / <<<	 Ch -
 Angle	 Format	 Stop	 Stop
 Menu	 Menu	 Pause	 Pause





Originale		Sostituto		Originale		Sostituto	
	Repeat 1-ALL		Text				
	Repeat A-B		+ 	Shift + Play			

