







































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Menu		Menu / Home
	Mute		Mute / Dimmer		Exit		Exit / Cancel / Clear
	Nicam/A2		Shift + Audio / Lang I/II		1		1
	Sleep		Sleep / Timer		2		2
	Aspect		Zoom / Size		3		3
	USB/CR		Shift + 8		4		4
	Display		Display / Media		5		5
	Auto		Smart / List		6		6
	PMode		Picture / Format		7		7
	SMode		Sound / Title		8		8
	DTV		D.Menu / Top		9		9
	Source		AV / Input / RDS		0		0
	Up		Up		-/-		Guide / EPG / -/-
	Left		Left		Back		Back / Return
	Enter		OK		CH+		CH+ / Page+
	Right		Right		Info		Info / Angle
	Down		Down		Audio		Audio / Lang I/II





Originale	Sostituto	Originale	Sostituto
Vol+	Vol+	Yellow	Yellow / YouTube / Repeat
CH-	CH- / Page-	Cyan	Blue / Prime Video / Random
FAV	Fav / Marker / PC		
Tv/Radio	TV/Radio /		
Vol-	Vol-		
Text	Text / Goto		
Play	Play / Slow		
Pause	Pause / Step / Freeze		
Stop/EPG	Stop / Hold		
Subtitle	Subtitle / EQ		
Rec/Hold	Rec / Rec Mode		
<</Index	<< / Tune-		
>>/Size	>> / Tune+		
I<</Reveal	I<< / Preset-		
>>I/Sbpage	>>I / Preset+		
Red	Red / Netflix / Search		
Green	Green / APP / Repeat		

Originale	Sostituto
Yellow	Yellow / YouTube / Repeat
Cyan	Blue / Prime Video / Random

