



Originale	Sostituto
 Power	 Power
 Mute	 Mute
 Play	 Play
 Pause	 Pause
 Stop	 Stop
 USB	 Media
 Rec	 Rec
 Info	 Info
 I<<<	 I<<<
 >>>I	 >>>I
 <<<	 <<<
 >>>	 >>>
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 FAV	 Pre Ch

Originale	Sostituto
 SAT	 Smart
 Menu	 Menu
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Subtitle	 Subt
 TXT	 Text
 Recall	 Back
 Audio	 Dual
 Page+	 Ch +
 Page-	 Ch -
 1	 1
 2	 2
 3	 3



