










































































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		-/--		Shift + Guide / EPG / -/--
	Mute		Mute / Dimmer		Recall		Back / Return
	Aspect		Shift + Picture / Format		Red		Red / Netflix / Search
	P.Mode		Picture / Format		Green		Green / APP / Repeat
	S.Mode		Sound / Title		Yellow		Yellow / YouTube / Repeat
	Audio / Nicam		Audio / Lang I/II		Blue		Blue / Prime Video / Random
	Sleep		Sleep / Timer		Source		AV / Input / RDS
	1		1		Up		Up
	2		2		Menu		Menu / Home
	3		3		Left		Left
	4		4		Enter		OK
	5		5		Right		Right
	6		6		Down		Down
	7		7		Vol +		Vol+
	8		8		Exit		Exit / Cancel / Clear
	9		9		CH +		CH+ / Page+
	0		0		Vol -		Vol-





Originale	Sostituto
 Display	 Display / Media
 CH -	 CH- / Page-
 TXT	 Text / Goto
 Index	 Setup / OPT /
 Hold	 Shift + Stop /
 Mix	 Shift + Text /
 Subpage	 Eject / Surround
 Reveal / Subtitle	 Subtitle / EQ
 Size	 Zoom / Size
 Rec / Goto /	 Rec / Rec Mode
 EPG	 Guide / EPG / -/--
 List	 Smart / List
 TV / Radio	 TV/Radio /
 FAV	 Fav / Marker / PC
 Play / Pause	 Play / Slow
 Play / Pause	 Shift + Play /
 Stop	 Stop / Hold

Originale	Sostituto
 PVR Menu	 D.Menu / Top
 Media	 Shift + Display / Media
 I<<	 I<< / Preset-
 >>I	 >>I / Preset+
 <<	 << / Tune-
 >>	 >> / Tune+

