



Originale	Sostituto
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Mute	Mute
Pause	Pause
Recall	Back
Menu	Menu
Red / Sleep	Red
Red / Sleep	SHIFT +  Power

Originale	Sostituto
Green / List	Green
Green / List	List
Yellow / <<	Yellow
Yellow / <<	<<
Blue / >>	Blue
Blue / >>	>>
Exit	Exit
Up	Up
Left	Left
OK	Ok
Right	Right
Down	Down
9PIC	Media
Audio	Dual
TV / Radio	TV/R
TV / VCR	AV
N / P	3D





Originale		Sostituto		Originale		Sostituto	
	FAV		Pre Ch				
	Text		Text				
	EPG		Guide				
	Subtitle		Subt				
	Info		Info				

