







































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Vol-		Vol-
	Source		AV / Input / RDS		Mute		Mute / Dimmer
	Display		Display / Media		CH-		CH- / Page-
	1		1		Menu		Menu / Home
	2		2		Back		Back / Return
	3		3		Up		Up
	4		4		Left		Left
	5		5		OK		OK
	6		6		Right		Right
	7		7		Down		Down
	8		8		Guide		Guide / EPG / -/-
	9		9		FAV		Fav / Marker / PC
	Teletext		Text / Goto		Red		Red / Netflix / Search
	0		0		Green		Green / APP / Repeat
	Subtitle		Subtitle / EQ		Yellow		Yellow / YouTube / Repeat
	Vol+		Vol+		Blue		Blue / Prime Video / Random
	CH+		CH+ / Page+		Index / I<<		I<< / Preset-



