





































































Originale	Sostituto
 Standby	 Power
 Menu	 Menu
 Input TV	 TV/R
 Input AV	 AV
 Text	 Text
 Media Player	 Media
 Guide	 Guide
 [≡♦]/Still	 Format
 Exit	 Exit
 i	 Info
 Return/Back	 Back
 Option	 Options
 [+]/Aspect	 3D
 Mute	 Mute
 Red	 Red
 Green	 Green
 Yellow	 Yellow

Originale	Sostituto
 Blue	 Blue
 Vol+	 Vol +
 Vol-	 Vol -
 CH+	 Ch +
 CH-	 Ch -
 1	 1
 2 _{abc}	 2
 3 _{def}	 3
 4 _{ghi}	 4
 5 _{jkl}	 5
 6 _{mno}	 6
 7 _{pqrs}	 7
 8 _{tuv}	 8
 9 _{wxyz}	 9
 0	 0
 Last View	 Pre Ch
 Still	 Smart





Originale		Sostituto		Originale		Sostituto	
	OK		Ok				
	Up		Up				
	Down		Down				
	Right		Right				
	Left		Left				

