



| Originale | Sostituto |
|-------------|--------------------------|
| Power | Power |
| Guide | Guide / EPG / -/-- |
| Tv Input | AV / Input / RDS |
| AV Input | Shift + AV / Input / RDS |
| Menu | Menu / Home |
| Text | Text / Goto |
| [=◇]/STTL | Subtitle / EQ |
| [=+]/Aspect | Picture / Format |
| i | Info / Angle |
| Exit | Exit / Cancel / Clear |
| Netflix | Shift + Red / Netflix / |
| APPS | Smart / List |
| Left | Left |
| Up | Up |
| Right | Right |
| Home | Shift + Menu / |
| OK | OK |

| Originale | Sostituto |
|-------------|-----------------------------|
| Option | Setup / OPT / |
| Down | Down |
| Back/Return | Back / Return |
| Red | Red / Netflix / Search |
| Green | Green / APP / Repeat |
| Yellow | Yellow / YouTube / Repeat |
| Blue | Blue / Prime Video / Random |
| Vol+ | Vol+ |
| Mute | Mute / Dimmer |
| PR+ | CH+ / Page+ |
| Vol- | Vol- |
| PR- | CH- / Page- |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |



