


























































Originale	Sostituto
 Power	 Power
 Select Drive	 List
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Last View	 Pre Ch
 Radio/Tv	 TV/R
 CH/Page+	 Ch +
 CH/Page-	 Ch -
 Internet	 Smart

Originale	Sostituto
 Netflix	 Media
 I<< Skip	 I<<
 Skip >>I	 >>I
 << Slow/Search	 <<
 Slow/Search >>	 >>
 Stop	 Stop
 Pause/PAUSE Live	 Pause
 Play	 Play
 Rec	 Rec
 i/STATUS	 Info
 X/EXIT	 Exit
 Video Menu	 D. Menu
 Guide	 Guide
 Function Menu	 Menu
 Option	 Options
 Return	 Back
 Up	 Up





Originale	Sostituto
 Down	 Down
 Right/II>	 Right
 <II/Left	 Left
 OK	 Ok
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Rec Mode	 +  Shift + Rec
 Text	 TEXT Text
 STTL	 SUBT Subt
 Prog/Check	 SLEEP Sleep
 Chapter	 FORMAT Format
 Time Slip	 3D 3D
 Audio	 DUAL Dual
 Input Select	 AV AV
 Delete	 Eject

Originale	Sostituto
 Manual Skip -10s	 +  Shift + Left
 Manual Skip +60s	 +  Shift + Right
 Power Tv	 +  Shift + Power
 AV Input Tv	 +  Shift + AV
 Vol+ Tv	 Vol +
 Vol- Tv	 Vol -
 CH+ Tv	 +  Shift + Ch +
 CH- Tv	 +  Shift + Ch -

