







































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Yellow		Yellow
	Picture		Format		Blue		Blue
	J/Sound		Dual		[≡♦]/FP		TV/R
	Set Up		Menu		[≡i]/Index		Smart
	CH+		Ch +		[≡+]/Hold/Still		Options
	CH-		Ch -		Tv/Text		Text
	Up		Up		Direct Tv Rec		Rec
	Down		Down		OIO		List
	Right		Right		Aspect		3D
	Left		Left		1		1
	Vol+		Vol +		2		2
	Vol-		Vol -		3		3
	Mute		Mute		4		4
	[+]		Info		5		5
	Tv/AV		AV		6		6
	Red		Red		7		7
	Green		Green		8		8









