



Originale	Sostituto
	 Power
	 Sleep
	 Shift + Power
	 Info
	 Shift + AV
	 Media
	 Rec
	 Smart
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9

Originale	Sostituto
	 0
	 Guide
	 Shift + Sleep
	 Shift + Play
	 Play
	 TV/R
	 Stop
	 Exit
	 Pause
	 AV
	 Vol -
	 Vol +
	 <<<
	 I<<<
	 >>>
	 >>I
	 Dual



