



Originale		Sostituto	
	Power		Power
	Freeze		Pause / Step / Freeze
	Auto Setup		Setup / OPT /
	Shutter		AV / Input / RDS
	Menu		Menu / Home
	Up		Up
	Left		Left
	Enter		OK
	Right		Right
	Down		Down
	Vol+		Vol+
	Index Window		Smart / List
	D.Zoom+		CH+ / Page+
	Vol-		Vol-
	STD		Display / Media
	D.Zoom-		CH- / Page-
	Input Video		4

Originale		Sostituto	
	Input RGB		Guide / EPG / -/--

