









































































































Originale	Sostituto
 Power TV	 Power
 1 TV	 1
 2 TV	 2
 3 TV	 3
 4 TV	 4
 5 TV	 5
 6 TV	 6
 7 TV	 7
 8 TV	 8
 9 TV	 9
 0/-- TV	 0
 AV TV	 AV
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Return TV	 Back
 PR+ TV	 Ch +

Originale	Sostituto
 PR- TV	 Ch -
 Play TV	 Play
 << TV	 <<
 >> TV	 >>
 Record TV	 Rec
 Stop TV	 Stop
 Pause TV	 Pause
 Exit TV	 Exit
 Menu TV	 Menu
 Violet/Text TV	 Text
 Red/Presets TV	 Red
 Green/List TV	 Green
 Yellow/Info TV	 Yellow
 Blue/Guide TV	 Blue
 Up TV	 Up
 Down TV	 Down
 Right/Zoom+	 Right





Originale	Sostituto
 Left/Zoom- TV	 Left
 OK TV	 Ok
 TV	 TV/R
 Demo TV	 Pre Ch
 VCR	 Smart
 SAT	 Media
 DVD	 Options
 AUX	 Format
 AMP	 3D
 Power AUX	 Shift + Power
 Red/Presets	 Shift + Red
 Green/List AUX	 Shift + Green
 Yellow/Info AUX	 Shift + Yellow
 Blue/Guide AUX	 Shift + Blue
 Up AUX	 Shift + Up
 OK AUX	 Shift + Ok
 Down AUX	 Shift + Down

Originale	Sostituto
 Right/Zoom+	 Shift + Right
 Left/Zoom- AUX	 Shift + Left
 Exit AUX	 Shift + Exit
 Menu AUX	 Shift + Menu
 Violet/Text AUX	 Shift + Text
 Return AUX	 Shift + Back
 PR+ AUX	 Shift + Ch +
 PR- AUX	 Shift + Ch -
 1 AUX	 Shift + 1
 2 AUX	 Shift + 2
 3 AUX	 Shift + 3
 4 AUX	 Shift + 4
 5 AUX	 Shift + 5
 6 AUX	 Shift + 6
 7 AUX	 Shift + 7
 8 AUX	 Shift + 8
 9 AUX	 Shift + 9









































































Originale	Sostituto	Originale	Sostituto
0 AUX	+ Shift + 0		
Play AUX	+ Shift + Play		
<< AUX	+ Shift + <<		
>> AUX	+ Shift + >>		
Stop AUX	+ Shift + Stop		
Record AUX	+ Shift + Rec		
Pause AUX	+ Shift + Pause		
AV AUX	+ Shift + AV		
Demo AUX	+ Shift + Pre Ch		

Originale	Sostituto





Originale		Sostituto		Originale		Sostituto	
	Power DVD		Power		PR+ DVD		Ch +
	Red/Presets		Red		PR- DVD		Ch -
	Green/List DVD		Green		1 DVD		1
	Yellow/Info DVD		Yellow		2 DVD		2
	Blue/Guide DVD		Blue		3 DVD		3
	Violet/Text DVD		Text		4 DVD		4
	Up DVD		Up		5 DVD		5
	Down DVD		Down		6 DVD		6
	Right/Zoom+		Right		7 DVD		7
	Left/Zoom- DVD		Left		8 DVD		8
	OK DVD		Ok		9 DVD		9
	Exit DVD		Exit		0 DVD		0
	Menu DVD		Menu		AV DVD		AV
	Vol+		Vol +		Demo DVD		Pre Ch
	Vol-		Vol -		Play DVD		Play
	Mute		Mute		<< DVD		<<
	Return DVD		Back		>> DVD		>>






Originale	Sostituto
Record DVD	Rec
Stop DVD	Stop
Pause	Pause
TV	TV/R
VCR	Smart
SAT	Media
DVD	Options
AUX	Format
AMP	3D
Power VCR	Shift + Power
Red/Presets	Shift + Red
Green/List VCR	Shift + Green
Yellow/Info VCR	Shift + Yellow
Blue/Guide VCR	Shift + Blue
Violet/Text VCR	Shift + Text
Exit VCR	Shift + Exit
Menu VCR	Shift + Menu

Originale	Sostituto
Up VCR	Shift + Up
Down VCR	Shift + Down
Right/Zoom+	Shift + Right
Left/Zoom- VCR	Shift + Left
OK VCR	Shift + Ok
Return VCR	Shift + Back
PR+ VCR	Shift + Ch +
PR- VCR	Shift + Ch -
1 VCR	Shift + 1
2 VCR	Shift + 2
3 VCR	Shift + 3
4 VCR	Shift + 4
5 VCR	Shift + 5
6 VCR	Shift + 6
7 VCR	Shift + 7
8 VCR	Shift + 8
9 VCR	Shift + 9





























































	Originale	Sostituto	
	0 VCR	 + 	Shift + 0
	<< VCR	 + 	Shift + <<
	>> VCR	 + 	Shift + >>
	Play VCR	 + 	Shift + Play
	AV VCR	 + 	Shift + AV
	Stop VCR	 + 	Shift + Stop
	Record VCR	 + 	Shift + Rec
	Pause VCR	 + 	Shift + Pause

Originale	Sostituto
























Originale	Sostituto	Originale	Sostituto
	Power		Power
	TV		TV/R
	VCR		Smart
	SAT		Media
	DVD		Options
	AUX		Format
	AMP		3D
	Red/Presets		Red
	Green/List		Green
	Yellow/Info		Yellow
	Blue/Guide		Blue
	Violet/Text		Text
	Up		Up
	Down		Down
	Right/Zoom+		Right
	Left/Zoom-		Left
	OK		Ok
	Exit		Exit
	Menu		Menu
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Return		Back
	PR+		Ch +
	PR-		Ch -
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9





	Originale	Sostituto	Originale	Sostituto
	0			
	AV			
	Demo			
	<<			
	Play			
	>>			
	Record			
	Stop			
	Pause			




















Originale	Sostituto
	
Power	Power
	
TV	TV/R
	
VCR	Smart
	
SAT	Media
	
DVD	Options
	
AUX	Format
	
AMP	3D
	
Red/Presets	Red
	
Yellow/Info	Yellow
	
Blue/Guide	Blue
	
Violet/Text	Text
	
Up	Up
	
Down	Down
	
Right/Zoom+	Right
	
Left/Zoom-	Left
	
OK	Ok
	
Exit	Exit

Originale	Sostituto
	
Menu	Menu
	
Vol+	Vol +
	
Vol-	Vol -
	
Mute	Mute
	
Return	Back
	
PR+	Ch +
	
PR-	Ch -
	
1	1
	
2	2
	
3	3
	
4	4
	
5	5
	
6	6
	
7	7
	
8	8
	
9	9
	
0	0




Originale
Sostituto

	AV		AV
	<<		<<
	Play		Play
	>>		>>
	Record		Rec
	Stop		Stop
	Pause		Pause

Originale
Sostituto

