







































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 △	 Smart
 Ambilight	 3D	 Red	 Red
 Source	 AV	 Green	 Green
 Settings	 Options	 Yellow	 Yellow
 Top Picks	 D. Menu	 Blue	 Blue
 Search	 TV/R	 Vol+	 Vol +
 TV/Exit	 Exit	 Vol-	 Vol -
 Tv Guide	 Guide	 Mute	 Mute
 Windows	 Info	 Netflix	 Media
 List	 List	 Ch +	 Ch +
 Up	 Up	 Ch -	 Ch -
 Down	 Down	 1	 1
 Right	 Right	 2	 2
 Left	 Left	 3	 3
 OK	 Ok	 4	 4
 ←	 Back	 5	 5
 +	 Format	 6	 6



