

































































Originale	Sostituto
 Power	 Power
 >>>	 +  Shift + Menu
 Source	 AV
 I - II	 Dual
 Subtitles	 Subt
 [i+]	 Info
 [?]	 D. Menu
 Mix	 TV/R
 Zoom	 Eject
 Time	 +  Shift + AV
 [PP]	 Back
 DNR	 Options
 Mosaic	 Guide
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left


Originale	Sostituto
 Red / Menu	 Red
 Red / Menu	 +  Shift + Format
 Green / Menu	 Green
 Green / Menu	 +  Shift + Dual
 Yellow / Other	 Yellow
 Yellow / Other	 Menu
 Blue / OK	 Blue
 Blue / OK	 Ok
 Special Audio	 +  Shift + Subt
 Text	 Text
 P -	 Ch -
 P +	 Ch +
 Vol -	 Vol -
 Vol +	 Vol +
 1	 1
 2	 2
 3	 3





































	Originale	Sostituto	Originale	Sostituto
	4			
	5			
	6			
	7			
	8			
	9			
	0			
	Mute			
	P < P			
	Format			
	Freeze			
	Smart Controls Picture			
	Smart Controls Audio			





Originale	Sostituto	Originale	Sostituto
	Power		Power
	Time		TV/R
	Zoom		3D
	Mix		Text
	[?]		Shift + Info
	[i+]		Info
	Freeze/Rec		Pause
	Format/Stop		Format
	Source		AV
	I-II		Dual
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Rec		Rec
	<<		<<
	>>		>>

Originale	Sostituto	Originale	Sostituto
	Stop		Stop
	Play		Play
	Timer		Shift + AV
	P-		Ch -
	P +		Ch +
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/-		Guide

