



Originale	Sostituto
 Teletext	 Text / Goto
 Standby	 Power
 Red	 Red / Netflix / Search
 Green/Smart []	 Green / APP / Repeat
 Green/Smart []	 Picture / Format
 Yellow/Smart ♪	 Yellow / YouTube / Repeat
 Yellow/Smart ♪	 Sound / Title
 Blue	 Blue / Prime Video / Random
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9

Originale	Sostituto
 Clear	 Exit / Cancel / Clear
 0	 0
 Timer	 Sleep / Timer
 Menu	 Menu / Home
 Up	 Up
 P+	 CH+ / Page+
 OK	 OK
 Vol-	 Vol-
 Left	 Left
 Right	 Right
 Vol+	 Vol+
 Mute	 Mute / Dimmer
 P-	 CH- / Page-
 Down	 Down
 P<P	 Back / Return
 Play	 Play / Slow
 <<	 << / Tune-



