























































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		[i+]/Info		Info / Angle
	Tv/DTV		TV/Radio /		0		0
	Input1		Shift + 1		P+		CH+ / Page+
	Input2		Shift + 2		I-II		Audio / Lang I/II
	Input3		Shift + 3		Vol+		Vol+
	Input4		Shift + 4		P-		CH- / Page-
	[> <]/[≡+]		D.Menu / Top		Mute		Mute / Dimmer
	[<>]/[≡♦]		Picture / Format		Vol-		Vol-
	1		1		Return		Back / Return
	2		2		Up		Up
	3		3		Home Menu		Menu / Home
	4		4		Left		Left
	5		5		Enter		OK
	6		6		Right		Right
	7		7		Exit		Exit / Cancel / Clear
	8		8		Down		Down
	9		9		EPG		Guide / EPG / -/-





Originale	Sostituto
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 [....]	 Subtitle / EQ
 [≡?]	 Display / Media
 [≡i]	 Smart / List
 [≡]	 Text / Goto

Originale	Sostituto

