











































































































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 P +	 Ch +
 1	 1	 P -	 Ch -
 2	 2	 Vol+	 Vol +
 3	 3	 Vol-	 Vol -
 4	 4	 Mute	 Mute
 5	 5	 Source Power	 AV
 6	 6	 Return	 Back
 7	 7	 Home	 Menu
 8	 8	 Up	 Up
 9	 9	 Down	 Down
 0	 0	 Right	 Right
 PC	 Pre Ch	 Left	 Left
 [i+]	 Info	 Enter	 Ok
 Split Screen	 Options	 Exit	 Exit
 Split Screen Swap	 3D	 EPG / DVD Top Menu / Guide	 Guide
 PIP Swap	 Shift + Back	 Red/Rec	 Red
 Tv/DTV	 TV/R	 Green/Pause	 Green





































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Down	 Down
 1	 1	 Right	 Right
 2	 2	 Left	 Left
 3	 3	 Enter	 Ok
 4	 4	 Menu	 Menu
 5	 5	 DVD Top	 D. Menu
 6	 6	 Return	 Back
 7	 7	 Play	 Play
 8	 8	 Stop	 Stop
 9	 9	 Pause	 Pause
 0	 0	 >>	 >>
 PC	 Pre Ch	 <<	 <<
 Source Power	 AV	 >>	 >>
 Mute	 Mute	 <<	 <<
 Vol +	 Vol +	 Input 1	 Shift + 1
 Vol -	 Vol -	 Input 2	 Shift + 2
 Up	 Up	 Input 3	 Shift + 3







































Originale	Sostituto	Originale	Sostituto
	Power		Power
	Source Power		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	PC		Pre Ch
	[i+]		Info
	Mute		Mute
	Vol +		Vol +
	Vol -		Vol -
	P +		Ch +
	P -		Ch -
	Menu		Menu
	Exit		Exit
	DVD Top Menu		D. Menu
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter		Ok
	Input 1		Shift + 1
	Input 2		Shift + 2
	Input 3		Shift + 3
	Input 4		Shift + 4
	Input 5		Shift + 5





Originale	Sostituto
 Power	 Power
 Source Power	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 PC	 Pre Ch
 Vol+	 Vol +
 Vol-	 Vol -
 P +	 Ch +
 P -	 Ch -

Originale	Sostituto
 Mute	 Mute
 Play	 Play
 Stop	 Stop
 Pause	 Pause
 Rec	 Rec
 >>	 >>
 <<	 <<
 Input 1	 Shift + 1
 Input 2	 Shift + 2
 Input 3	 Shift + 3
 Input 4	 Shift + 4
 Input 5	 Shift + 5

