







































































| Originale | | Sostituto | | Originale | | Sostituto | |
|---|------------------|--|---------------|---|--------------|---|---------------|
|  | Standby / On |  | Power |  | USB Rec |  | Rec |
|  | Function |  | List |  | Display |  | Info |
|  | Open / Close |  | Eject |  | Vol+ |  | Vol + |
|  | Home Media |  | Media |  | Vol- |  | Vol - |
|  | Karaoke |  | Guide |  | Mute |  | Mute |
|  | Mic Vol+ |  | Ch + |  | Top Menu |  | D. Menu |
|  | Mic Vol- |  | Ch - |  | Menu / PopUp |  | Menu |
|  | Resolution |  | Format |  | Up |  | Up |
|  | Net Contents |  | Shift + Media |  | Left |  | Left |
|  | Key Lock |  | Pre Ch |  | Enter |  | Ok |
|  | Dimmer |  | Shift + Mute |  | Right |  | Right |
|  | Sleep |  | Sleep |  | Down |  | Down |
|  | Exit |  | Exit |  | Home Menu |  | Smart |
|  | Virtual 3D Sound |  | 3D |  | Return |  | Back |
|  | Sound |  | Dual |  | Tools |  | Options |
|  | Sound Retriever |  | Shift + Dual |  | Continued |  | Shift + Play |
|  | CD/SACD |  | AV |  | Skip Search |  | Shift + Right |





| Originale | Sostituto |
|----------------|----------------|
| REV | << |
| Play | Play |
| FWD | >> |
| I<< / < / < | I<< |
| Pause | Pause |
| Stop | Stop |
| >> / > / > | >> |
| Audio | TV/R |
| Subtitle | Subt |
| Angle | Shift + Format |
| Repeat | Text |
| A-B | Shift + Text |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |

| Originale | Sostituto |
|------------------------|---------------|
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| 0 | 0 |
| Clear | Shift + Exit |
| Program / Red | Red |
| Program / Red | Shift + Sleep |
| RDS / Bookmark / Green | Green |
| PTY / Zoom / Yellow | Yellow |
| PTY / Zoom / | Shift + Eject |
| Index / Blue | Blue |
| | |
| | |
| | |
| | |
| | |

