







































| Originale | Sostituto |
|--|--|
|  Power |  Power |
|  Mute |  Mute |
|  Source |  AV |
|  PMode |  Format |
|  SMode |  Shift + Dual |
|  I/II |  Dual |
|  Sleep |  Sleep |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |

| Originale | Sostituto |
|--|---|
|  -/-- |  Shift + Guide |
|  TV Menu |  Menu |
|  DVB Menu |  D. Menu |
|  D.Exit |  Exit |
|  QV |  Pre Ch |
|  Call |  Back |
|  Up |  Up |
|  Left |  Left |
|  OK |  Ok |
|  Right |  Right |
|  Down |  Down |
|  V- |  Vol - |
|  V+ |  Vol + |
|  P- |  Ch - |
|  P+ |  Ch + |
|  Red |  Red |
|  Green |  Green |



