



Originale	Sostituto
Power	Power
Input	AV / Input / RDS
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
Info	Info / Angle
0	0
EPG	Guide / EPG / -/--
Vol+	Vol+
Mute	Mute / Dimmer
Menu	Menu / Home

Originale	Sostituto
P+	CH+ / Page+
Vol-	Vol-
APP	Shift + Green / APP /
P-	CH- / Page-
Up	Up
Left	Left
OK	OK
Right	Right
Back	Back / Return
Down	Down
X/Exit	Exit / Cancel / Clear
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
Audio	Audio / Lang I/II
[...] / Sub	Subtitle / EQ



