



Originale	Sostituto
Power	Power
Mute	Mute
Audio	Dual
TV / STB	Shift + TV/R
TV / R	TV/R
Sleep	Sleep
SUB	Subt
TXT	Text
Multi	Smart
P / N	Shift + 1
Recall	Pre Ch
1	1
2	2
3	3
4	4
5	5
6	6

Originale	Sostituto
7	7
8	8
9	9
0	0
PGUP	Vol +
PGDN	Vol -
SAT	Shift + AV
FAV +	Ch +
FAV -	Ch -
EPG	Guide
Fav	Shift + Pre Ch
Up / CH+	Up
Right / Vol+	Right
Down / CH-	Down
Left / Vol-	Left
OK	Ok
Menu	Menu



