



































Originale	Sostituto	Originale	Sostituto
On/Off	 Power	OK Enter	 Ok
Mute	 Mute	Menu Right	 Right
Update	 Play	Menu Off	 Exit
Reveal	 Pause	Menu Down	 Down
Txt Stop	 Stop	Back	 Back
Info	 Rec	Volume+	 Vol +
Subt.List	 Subt	Chan.Up	 Ch +
Sleep Timer	 Sleep	Volume-	 Vol -
Return TV	 TV/R	Menu audio	 Media
Menu video	 D. Menu	Chan.Down	 Ch -
Text	 Text	1	 1
Txt Expand	 Eject	2	 2
TV/AV	 AV	3	 3
Menu	 Menu	4	 4
Menu Up	 Up	5	 5
Display	 Info	6	 6
Menu Left	 Left	7	 7



Originale	Sostituto	Originale	Sostituto
8		8	
9		9	
Guide -/-- 1.		Guide	
0/10		0	
2.Fav P/C 2.		Pre Ch	
Red		Red	
Green		Green	
Yellow		Yellow	
Blue		Blue	
Audio-		Shift + Play	
Audio+		Shift + Pause	
Tone-		Shift + Stop	
Tone+		Shift + Rec	
On/Tim		Shift + Subt	
Mix Scan		Shift + TV/R	
Game Coo		Shift + Eject	
AV 2		Shift + AV	
Search		Shift + Up	
Disp		Shift + Info	
Tune-		Shift + Left	
Aft/Caf		Shift + Ok	
Tune+		Shift + Right	
Bright- Sys		Shift + Exit	
Store		Shift + Down	
Browse		Shift + Back	
Input		Shift + Vol +	
Contrast+		Shift + Ch +	
Output		Shift + Vol -	
Color- S.Std		Shift + Media	
Contrast-		Shift + Ch -	
On Pip		Shift + 1	
Swap		Shift + 2	
Rotate Pip		Shift + 3	
Still		Shift + 4	



