











| Originale | Sostituto |
|-----------|-----------|
| Standby | Power |
| Mute | Mute |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| 0 | 0 |
| Display | Info |
| Recall | Back |
| Setup | Menu |
| EPG | Guide |
| Source | AV |

| Originale | Sostituto |
|-------------|--------------|
| Audio | Dual |
| Subtitle | Subt |
| CH.List | List |
| FAV | Pre Ch |
| Up | Up |
| Down | Down |
| Right | Right |
| Left | Left |
| Ok | Ok |
| Vol+ | Vol + |
| Vol- | Vol - |
| Exit/Cancel | Exit |
| S.Mode | Shift + Dual |
| P.Mode | Format |
| CH+/Page+ | Ch + |
| CH-/Page- | Ch - |
| Red/Goto | Red |





| Originale | Sostituto |
|---|---|
|  Green/A-B |  Green |
|  Yellow/Repeat |  Yellow |
|  Blue/Angle |  Blue |
|  Record |  Rec |
|  Rec. List |  Smart |
|  TV/Radio |  TV/R |
|  Scaler |  3D |
|  Play |  Play |
|  Pause/Reveal |  Pause |
|  Stop/Index |  Stop |
|  Mix |  I<< |
|  Mix |  << |
|  Text |  >>I |
|  Text |  >> |
|  Text |  Text |
|  S. Page / |  D. Menu |
|  Hold/Title |  Media |

| Originale | Sostituto |
|--|--|
|  Zoom+/Size |  Shift + Ch + |
|  Zoom- |  Shift + Ch - |
|  Eject |  Eject |
|  Sleep |  Sleep |

