










































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Tv Pre-CH		Back
	Tv Power	 + 	Shift + Power		Dimmer		0
	Source		AV		I<<		I<<
	Auto Power		Sleep		Stop		Stop
	Speaker		Pre Ch		Play		Play
	Tv Source	 + 	Shift + AV		Pause		Pause
	Repeat		Text		>>I		>>I
	Any net		Media		Sound Effect		Menu
	Soundshare		Dual		Smart Volume		Smart
	Tv Vol+	 + 	Shift + Vol +		3D Sound Plus		3D
	Tv Vol-	 + 	Shift + Vol -		DRC		Subt
	Tv CH+		Ch +		Right S/W Level		Right
	Tv CH-		Ch -		Left S/W Level		Left
	Audio Sync+		3		Vol+		Vol +
	Audio Sync-		6		Vol-		Vol -
	Tv Mute	 + 	Shift + Mute		Mute		Mute
	Tv Info		Info				

