




















Originale	Sostituto
	Power
	Source
	1
	2
	3
	4
	5
	6
	7
	8
	9
	0
	TTX/MIX
	PRE-CH
	Mute
	CH List
	Vol+

Originale	Sostituto
	Vol-
	PR+
	PR-
	Menu
	Smart HUB
	Guide
	Tools
	Info
	Return
	Exit
	Up
	Down
	Left
	Right
	Enter
	Red
	Green





Originale		Sostituto		Originale	Sostituto
	Yellow		Yellow / YouTube / Repeat		
	Blue		Blue / Prime Video / Random		
	E-Manual		TV/Radio /		
	3D		Zoom / Size		
	AD/Subt.		Subtitle / EQ		
	Stop		Stop / Hold		
	<</ <<		<< / Tune-		
	Play		Play / Slow		
	Pause		Pause / Step / Freeze		
	>>/>>		>> / Tune+		

