





































| Originale | Sostituto |
|--------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------|
|  Power |  Power |
|  Source |  AV / Input / RDS |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  -- |  Zoom / Size |
|  PRE-CH |  Back / Return |
|  Vol+ |  Vol+ |
|  Vol- |  Vol- |
|  Mute |  Mute / Dimmer |

| Originale | Sostituto |
|-----------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------|
|  CH List |  Shift + Smart / List |
|  CH+ |  CH+ / Page+ |
|  CH- |  CH- / Page- |
|  Menu |  Menu / Home |
|  Smart Hub |  Smart / List |
|  Guide |  Guide / EPG / -/- |
|  Extra |  TV/Radio / |
|  Info |  Info / Angle |
|  Return |  Shift + Back / Return |
|  Exit |  Exit / Cancel / Clear |
|  Up |  Up |
|  Down |  Down |
|  Left |  Left |
|  Right |  Right |
|  Enter |  OK |
|  Red |  Red / Netflix / Search |
|  Green |  Green / APP / Repeat |



