



Originale	Sostituto
ON/STAND-BY ON/STAND-BY	Power
AUTO SET	Auto
COMPUTER 1	Shift + Mode
COMPUTER 2	Shift + Auto
HDMI	Focus Volt
VIDEO	Shift + Video Comp
S-VIDEO	Mode
COMPONENT	Video Comp
Up	Up
Down	Down
Right	Right
Left	Left
SELECT	Enter
MENU	Menu
SCREEN	Shift + Focus Volt
KEYSTONE	Shift + Up
LAMP	Shift + Aspect Eco

Originale	Sostituto
INFO.	Help / Info
FREEZE	Freeze / Timer
NO SHOW	Source
P-TIMER	Shift + Freeze / Timer
IMAGE	3D / Invert
ASPECT	Eco / Aspect
D.ZOOM+	+ / Play
D.ZOOM-	- / Stop
VOLUME+	Vol + / Page +
VOLUME-	Vol - / Page -
MUTE	Blank / Mute

