























































Originale	Sostituto
 POWER	 Power
 INPUT	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 EPG	 Guide
 DTV/ATV	 TV/R
 ASPECT	 3D
 FREEZE	 Pause
 O/I/II	 Dual

Originale	Sostituto
 AD	 Shift + Subt
 [ i+ ]/[ ≡i ]	 Info
 P+	 Ch +
 P-	 Ch -
 VOL +	 Vol +
 VOL -	 Vol -
 MUTE	 Mute
 TEXT [ ≡ ]	 Text
 [ ... ]	 Subt
 Timer	 Shift + AV
 EXIT	 Exit
 ^	 Up
 v	 Down
 >	 Right
 <	 Left
 OK	 Ok
 MENU	 Menu





Originale		Sostituto		Originale		Sostituto	
	RETURN		Back				
	RED		Red				
	GREEN		Green				
	YELLOW		Yellow				
	BLUE		Blue				
	REVEAL [≡?]		Eject				
	TEXT HOLD		D. Menu				
	TEXT SIZE		Format				
	[≡x]		Options				

