




















| Originale | Sostituto |
|---|---|
|  Power |  Power |
|  Up / P+ |  Up |
|  Up / P+ |  CH+ / Page+ |
|  Menu |  Menu / Home |
|  Left |  Left |
|  Right |  Right |
|  Down / P- |  Down |
|  Down / P- |  CH- / Page- |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |

| Originale | Sostituto |
|---|---|
|  -- |  Guide / EPG / -/-- |
|  0 |  0 |
|  P < P |  Fav / Marker / PC |
|  PP |  Back / Return |
|  Vol+ |  Vol+ |
|  I-II |  Audio / Lang I/II |
|  Mute |  Mute / Dimmer |
|  Vol- |  Vol- |
|  Info |  Info / Angle |
|  Red |  Red / Netflix / Search |
|  Green |  Green / APP / Repeat |
|  Yellow |  Yellow / YouTube / Repeat |
|  Blue |  Blue / Prime Video / Random |
|  [TV] |  Shift + 1 |
|  [TV] |  TV/Radio / |
|  [AV] |  AV / Input / RDS |
|  [≡] |  Text / Goto |







































| Originale | | Sostituto | |
|-----------|---------|-------------------|-----------------------|
| TIME | [≡⊕] | EQ SUBTITLE | Subtitle / EQ |
| LANG | [/ ≡] | FORMAT PICTURE | Picture / Format |
| CLEAR | [≡X] | EXIT CANCEL | Exit / Cancel / Clear |
| SIZE | [≡⇅] | ZOOM | Zoom / Size |
| TITLE | [≡?] | MEDIA DISPLAY | Display / Media |
| TV/RADIO | [≡i] | LIST SMART | Smart / List |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Originale | Sostituto |
|-----------|-----------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |





| Originale | Sostituto |
|---|---|
|  Power |  Power |
|  Up / P+ |  Up |
|  Up / P+ |  CH+ / Page+ |
|  Menu |  Menu / Home |
|  Left |  Left |
|  Select |  OK |
|  Right |  Right |
|  Down / P- |  CH- / Page- |
|  Down / P- |  Down |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |

| Originale | Sostituto |
|--|---|
|  9 |  9 |
|  +10 |  Guide / EPG / -/- |
|  0 |  0 |
|  Repeat |  Green / APP / Repeat |
|  Search |  Red / Netflix / Search |
|  A→B |  Yellow / YouTube / Repeat |
|  Display |  Display / Media |
|  Audio |  Audio / Lang I/II |
|  Subtitle |  Subtitle / EQ |
|  Zoom |  Zoom / Size |
|  Prog |  TV/Radio / |
|  C |  Blue / Prime Video / Random |
|  Angle |  Info / Angle |
|  Return |  Back / Return |
|  Time |  Sleep / Timer |
|  << / Tune- |  << / Tune- |
|  >> / Tune+ |  >> / Tune+ |








































































| Originale | Sostituto | Originale | Sostituto |
|---|---|-----------|-----------|
|  |  I<< / Preset- | | |
|  |  >>I / Preset+ | | |
|  |  Play / Slow | | |
|  |  Pause / Step / Freeze | | |
|  |  Stop / Hold | | |
|  |  Title | | |
|  |  Sound / Title | | |
|  |  Open / Close | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Originale | Sostituto |
|-----------|-----------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |





| Originale | Sostituto | Originale | Sostituto |
|-------------|---|------------|---|
| On/Off |  Power | Menu Right |  Right |
| Mute |  Mute / Dimmer | Menu Down |  Down |
| Txt Stop |  Stop / Hold | Back |  Back / Return |
| Tone+ |  >> / Tune+ | Volume+ |  Vol+ |
| Lang |  Sound / Title | Chan.Up |  CH+ / Page+ |
| Menu audio |  Audio / Lang I/II | Volume- |  Vol- |
| Subt.List |  Subtitle / EQ | Display |  Display / Media |
| Txt Expand |  Zoom / Size | Chan.Down |  CH- / Page- |
| Sleep Timer |  Sleep / Timer | 1 |  1 |
| Return TV |  TV/Radio / | 2 |  2 |
| Menu video |  D.Menu / Top | 3 |  3 |
| Text |  Text / Goto | 4 |  4 |
| Menu |  Menu / Home | 5 |  5 |
| Menu Up |  Up | 6 |  6 |
| Info |  Info / Angle | 7 |  7 |
| Menu Left |  Left | 8 |  8 |
| OK Enter |  OK | 9 |  9 |

| Originale | Sostituto | Originale | Sostituto |
|------------|---|-----------|---|
| Menu Right |  Right | Menu Down |  Down |
| Menu Down |  Down | Back |  Back / Return |
| Back |  Back / Return | Volume+ |  Vol+ |
| Volume+ |  Vol+ | Chan.Up |  CH+ / Page+ |
| Chan.Up |  CH+ / Page+ | Volume- |  Vol- |
| Volume- |  Vol- | Display |  Display / Media |
| Display |  Display / Media | Chan.Down |  CH- / Page- |
| Chan.Down |  CH- / Page- | 1 |  1 |
| 1 |  1 | 2 |  2 |
| 2 |  2 | 3 |  3 |
| 3 |  3 | 4 |  4 |
| 4 |  4 | 5 |  5 |
| 5 |  5 | 6 |  6 |
| 6 |  6 | 7 |  7 |
| 7 |  7 | 8 |  8 |
| 8 |  8 | 9 |  9 |
| 9 |  9 | | |





| Originale | Sostituto |
|---------------|--|
| Guide -/-- 1. | GUIDE EPG Guide / EPG / -/-- |
| 0/10 | HDMI - SAT 0 0 |
| 2.Fav P/C 2. | PC FAV MARKER Fav / Marker / PC |
| Red | NETFLIX SEARCH Red / Netflix / Search |
| Green | APP REPEAT Green / APP / Repeat |
| Yellow | YouTube REPEAT A-B Yellow / YouTube / Repeat |
| Blue | Prime Video RANDOM Blue / Prime Video / Random |
| Lang | SHIFT + LANG I/II Shift + Audio / Lang I/II |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

| Originale | Sostituto |
|-----------|-----------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

