







































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Menu/Set	 Menu
 Mute	 Mute	 V.Size	 Eject
 Tv/Video	 TV/R	 MTS	 Media
 Sleep	 Sleep	 Sound	 Dual
 ◆ Bright	 Guide	 Picture	 Format
 PIP	 3D	 1	 1
 Exit	 Exit	 2	 2
 Text	 Text	 3	 3
 Pre PG	 Pre Ch	 4	 4
 Up	 Up	 5	 5
 Down	 Down	 6	 6
 Right	 Right	 7	 7
 Left	 Left	 8	 8
 PG+	 Ch +	 9	 9
 PG-	 Ch -	 0	 0
 Vol+	 Vol +	 Time	 AV
 Vol-	 Vol -	 Still	 Options





Originale	Sostituto
Red/Erase	A Red
Green/Skip	B Green
Yellow/Insert	C Yellow
Blue/Replace	D Blue
PG Info	DISPLAY INFO Info

Originale	Sostituto

