









































































































Originale		Sostituto		Originale		Sostituto	
	Source		AV / Input / RDS		[≡]/Text		Text / Goto
	Power		Power		Google Play		Display / Media
	Digital/Analog		Setup / OPT /		Netflix		Shift + Red / Netflix /
	Tv/Radio		TV/Radio /		Red		Red / Netflix / Search
	Sync Menu		Menu / Home		Green		Green / APP / Repeat
	Exit		Exit / Cancel / Clear		Yellow		Yellow / YouTube / Repeat
	1		1		Blue		Blue / Prime Video / Random
	2		2		Action Menu		D.Menu / Top
	3		3		Tv		Shift + 1
	4		4		Up		Up
	5		5		Guide		Guide / EPG / -/-
	6		6		Left		Left
	7		7		OK		OK
	8		8		Right		Right
	9		9		Back		Back / Return
	[i]/[?]		Info / Angle		Down		Down
	0		0		Home		Shift + Menu / Home





Originale	Sostituto
 Discover	 Picture / Format
 Vol+	 Vol+
 Recall	 Fav / Marker / PC
 Prog+	 CH+ / Page+
 Vol-	 Vol-
 Mute	 Mute / Dimmer
 Prog-	 CH- / Page-
 Audio	 Audio / Lang I/II
 <<<	 <<< / Tune-
 Play	 Play / Slow
 >>>	 >>> / Tune+
 [...]	 Subtitle / EQ
 I<<<	 I<<< / Preset-
 Pause	 Pause / Step / Freeze
 >>>I	 >>>I / Preset+
 Help	 Sleep / Timer
 Rec	 Rec / Rec Mode

Originale	Sostituto
 Stop	 Stop / Hold
 Title List	 Smart / List

