












Originale	Sostituto	Originale	Sostituto
Speakers TV Audio Bravia Sync	Shift + Sound / Title	Green	Green / APP / Repeat
Power AV Bravia Sync	Shift + Power	Yellow	Yellow / YouTube / Repeat
Power	Power	Blue	Blue / Prime Video / Random
1	1	Top Menu	D.Menu / Top
2	2	Up	Up
3	3	Left	Left
4	4	OK	OK
5	5	Right	Right
6	6	Return	Back / Return
7	7	Down	Down
8	8	Options	Setup / OPT /
9	9	Home/Menu	Menu / Home
♥	Fav / Marker / PC	Sound Mode	Sound / Title
[≡]	Text / Goto	I<</Preset-	I<< / Preset-
0	0	←	Shift + Left
Enter	Guide / EPG / -/--	→	Shift + Right
Red	Red / Netflix / Search	>>I/Preset+	>>I / Preset+

Originale	Sostituto	Originale	Sostituto
Green	Green / APP / Repeat	Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random	Top Menu	D.Menu / Top
Up	Up	Left	Left
OK	OK	Right	Right
Return	Back / Return	Down	Down
Options	Setup / OPT /	Home/Menu	Menu / Home
Sound Mode	Sound / Title	I<</Preset-	I<< / Preset-
←	Shift + Left	→	Shift + Right
>>I/Preset+	>>I / Preset+		





Originale	Sostituto
 <</Tuning-	 << / Tune-
 Play	 Play / Slow
 >>/Tuning+	 >> / Tune+
 [...]	 Subtitle / EQ
 Pause	 Pause / Step / Freeze
 Stop	 Stop / Hold
 Mute	 Mute / Dimmer
 Vol+	 Vol+
 Prog+	 CH+ / Page+
 Display	 Display / Media
 O)))	 Audio / Lang I/II
 Vol-	 Vol-
 Prog-	 CH- / Page-
 Sleep	 Sleep / Timer

Originale	Sostituto





Originale	Sostituto
Eject	Eject / Surround
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
♥	Fav / Marker / PC
0	0
Enter	Guide / EPG / -/--
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat

Originale	Sostituto
Blue	Blue / Prime Video / Random
Top Menu	D.Menu / Top
Up	Up
Pop Up Menu	Smart / List
Left	Left
OK	OK
Right	Right
Return	Back / Return
Down	Down
Options/Tools	Setup / OPT /
Function	Info / Angle
Home/Menu	Menu / Home
Sound Mode	Sound / Title
I<</Preset-	I<< / Preset-
←	Shift + Left
→	Shift + Right
>>I/Preset+	>>I / Preset+





Originale		Sostituto		Originale	Sostituto
	<</Tuning-		<< / Tune-		
	Play		Play / Slow		
	>>/Tuning+		>> / Tune+		
	[...]		Subtitle / EQ		
	Pause		Pause / Step / Freeze		
	Stop		Stop / Hold		
	Mute		Mute / Dimmer		
	Vol+		Vol+		
	Display		Display / Media		
	O)))		Audio / Lang I/II		
	Vol-		Vol-		
	Sleep		Sleep / Timer		





Originale	Sostituto
Speakers TV Audio Bravia Sync	Sound / Title
Power AV Bravia Sync	Shift + Power
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
♥ Fav / Marker / PC	Fav / Marker / PC
[=] Text / Goto	Text / Goto
0	0
Red Red / Netflix / Search	Red / Netflix / Search
Green Green / APP / Repeat	Green / APP / Repeat

Originale	Sostituto
Yellow Yellow / YouTube / Repeat	Yellow / YouTube / Repeat
Blue Blue / Prime Video / Random	Blue / Prime Video / Random
Top Menu D.Menu / Top	D.Menu / Top
Up Up	Up
Left Left	Left
OK OK	OK
Right Right	Right
Return Back / Return	Back / Return
Down Down	Down
Home/Menu Menu / Home	Menu / Home
[...] Subtitle / EQ	Subtitle / EQ
Mute Mute / Dimmer	Mute / Dimmer
Vol+ Vol+	Vol+
Prog+ CH+ / Page+	CH+ / Page+
Display Display / Media	Display / Media
Vol- Vol-	Vol-
Prog- CH- / Page-	CH- / Page-





Originale

Sostituto

Originale

Sostituto



Originale	Sostituto
 Sleep	 Sleep / Timer

Originale	Sostituto

