




















































| Originale | Sostituto |
|--|---|
|  Power |  Power |
|  Input |  AV |
|  Digital/Analog |  3D |
|  TV/Radio |  TV/R |
|  Exit |  Exit |
|  EXT.Box Menu |  D. Menu |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  [i+]/[?] |  Info |

| Originale | Sostituto |
|---|---|
|  [≡] |  Text |
|  Google Play |  Shift + Smart |
|  Netflix |  Media |
|  Red |  Red |
|  Green |  Green |
|  Yellow |  Yellow |
|  Blue |  Blue |
|  Guide |  Guide |
|  Action Menu |  Menu |
|  APPS |  Shift + Media |
|  Back |  Back |
|  TV |  Options |
|  Home |  Smart |
|  Up |  Up |
|  Down |  Down |
|  Right |  Right |
|  Left |  Left |





| Originale | Sostituto | Originale | Sostituto |
|---|-----------|---|-----------|
|  | OK |  | Ok |
|  | Vol+ |  | Vol + |
|  | Vol- |  | Vol - |
|  | Mute |  | Mute |
|  | Recall |  | Pre Ch |
|  | Prog+ |  | Ch + |
|  | Prog- |  | Ch - |
|  | Audio |  | Dual |
|  | << |  | << |
|  | Play |  | Play |
|  | >> |  | >> |
|  | l<< |  | l<< |
|  | Pause |  | Pause |
|  | >>l |  | >>l |
|  | Rec |  | Rec |
|  | Stop |  | Stop |
|  | [...] |  | Subt |

