














































Originale	Sostituto
 Power	 Power
 Social View	 Media
 Input	 AV
 Digital/Analog	 Eject
 Exit	 Exit
 Football	 List
 3D	 3D
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0

Originale	Sostituto
 TV/Radio	 TV/R
 [≡]	 Text
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 X/Related Search/Track ID	 Shift + TV/R
 Sync Menu	 Menu
 ?/i-Manual	 D. Menu
 Discover	 Sleep
 [i+]/[?]	 Info
 Return/Back	 Back
 Options	 Options
 Home	 Smart
 Guide	 Guide
 Up	 Up
 Down	 Down





Originale		Sostituto		Originale		Sostituto	
	Right		Right		>>		>>
	Left		Left		Rec		Rec
	OK		Ok		Stop		Stop
	Vol+		Vol +		Tv Pause		Shift + Pause
	Vol-		Vol -				
	Mute		Mute				
	Recall		Pre Ch				
	Prog+		Ch +				
	Prog-		Ch -				
	Audio		Dual				
	[...]		Subt				
	[+]		Format				
	<<		<<				
	Play		Play				
	>>		>>				
	<<		<<				
	Pause		Pause				

