







































































	Originale	Sostituto	Originale	Sostituto
	Power	 Power		 5
	→←	 List		 6
	[]	 3D		 7
	Power Video	 Shift + Power		 8
	Mute	 Mute		 9
	[]	 Smart		 0
	Text	 Text		 Guide
	[i+]	 Info		 Back
	□ / □	 Shift + 1		 Red
	Input	 AV		 Green
	[> <]	 Shift + 4		 Yellow
	□ / □	 Shift + 2		 Blue
	↑	 Shift + 3		 Up
	1	 1		 Left
	2	 2		 Ok
	3	 3		 Right
	4	 4		 Down





	Originale	Sostituto	
	Vol+	Vol +	
	Vol-	Vol -	
	Menu	Menu	
	Progr+	Ch +	
	Progr-	Ch -	
	[P]	Sleep	
	<<	<<	
	Play	Play	
	>>	>>	
	Stop	Stop	
	Pause	Pause	
	Rec	Rec	
	CH+	Shift + Ch +	
	CH-	Shift + Ch -	

Originale Sostituto





Originale

Sostituto

Originale

Sostituto





Originale

Sostituto

Originale


Sostituto





Originale

Sostituto



Originale

Sostituto

