





| Originale |          | Sostituto |               | Originale |          | Sostituto |                |
|-----------|----------|-----------|---------------|-----------|----------|-----------|----------------|
|           | Standby  |           | Power         |           | Vol-     |           | Vol -          |
|           | Auto     |           | Smart         |           | CH+      |           | Ch +           |
|           | Tv/Radio |           | TV/R          |           | CH-      |           | Ch -           |
|           | Mute     |           | Mute          |           | Nicam/A2 |           | Options        |
|           | 1        |           | 1             |           | Aspect   |           | 3D             |
|           | 2        |           | 2             |           | Display  |           | Info           |
|           | 3        |           | 3             |           | Up       |           | Up             |
|           | 4        |           | 4             |           | Down     |           | Down           |
|           | 5        |           | 5             |           | Right    |           | Right          |
|           | 6        |           | 6             |           | Left     |           | Left           |
|           | 7        |           | 7             |           | OK       |           | Ok             |
|           | 8        |           | 8             |           | Menu     |           | Menu           |
|           | 9        |           | 9             |           | Exit     |           | Exit           |
|           | 0        |           | 0             |           | Source   |           | AV             |
|           | -/--     |           | Shift + Guide |           | P.Mode   |           | Shift + Format |
|           | Back     |           | Back          |           | S.Mode   |           | Shift + Dual   |
|           | Vol+     |           | Vol +         |           | Sleep    |           | Sleep          |





| Originale   | Sostituto  |
|---|--|
|  Fav       |  Pre Ch       |
|  Fav-      |  Shift + Ch - |
|  Fav+      |  Shift + Ch + |
|  Hold      |  Shift + AV   |
|  EPG       |  Guide        |
|  Text      |  Text         |
|  Lang      |  Dual         |
|  Subtitle  |  Subt         |
|  Index     |  List         |
|  Reveal   |  Eject       |
|  Subpage |  D. Menu    |
|  Media   |  Media      |
|  Size    |  Format     |
|  Play    |  Play       |
|  Pause   |  Pause      |
|  <<      |  <<         |
|  >>      |  >>         |

| Originale  | Sostituto  |
|--|--|
|  Rec    |  Rec    |
|  Stop   |  Stop   |
|  I<<    |  I<<    |
|  >>I    |  >>I    |
|  Red    |  Red    |
|  Green  |  Green  |
|  Yellow |  Yellow |
|  Blue   |  Blue   |

